



Product Data Sheet

PRODUCT DESCRIPTION

OmniPrep is a premium quality, acrylic latex primer specifically designed for interior surfaces. It promotes adhesion to a variety of challenging substrates and resists bleed-through from both solvent-sensitive and water-sensitive stains. Highly resistant to alkalinity and efflorescence, OmniPrep can be applied to surfaces with a pH of 6 to 13, allowing for its use on concrete and masonry substrates in as little as 7 days.

TYPICAL USES

OmniPrep is designed to promote adhesion to interior fiberglass, ceramic tile, galvanized metal, aluminum, wood, drywall, plaster, masonry, many existing coatings including gloss alkyd coatings, and many more substrates.

BASES & COLORS (tintable with ACS colorant)

DU-1523 White 0–2 oz/gal

PHYSICAL PROPERTIES(DU-1523)

Resin Type	Acrylic Latex
Clean-up Solvent	Water
Finish	5–10 @ 85° / >5 @ 60°
Solids by Weight	49 %
Solids by Volume	34 %

Recommended Dry Film

Thickness per Coat 1.5–2 mils

Wet Film to Achieve DFT 4.5–6 mils

Theoretical Coverage

@ 1 mil 546 ft²/gallon

Practical Coverage at Recommended DFT¹

273–364 ft²/gallon

Dry Times²

@ 70° F (21° C) Touch ½ to 2 hours
and 50% R.H. Recoat 2 to 4 hours³

VOCs <50 grams/liter

¹ Spread rates are estimates based on products volume solids and make no allowance for material loss during application. Actual spread rates may vary dependent on applicator experience, surface porosity and texture.

² Dry times may vary depending upon temperature, humidity and degree of air movement.

³ For the best results when using as a stain blocker, allow 24 hours between coats: two (2) full coats may be required for optimum performance.

SPECIFICATIONS

Interior Aluminum

1 ct OmniPrep Primer
2 cts Interior Finish*

Interior Drywall

1 ct OmniPrep Primer
2 cts Interior Finish*

Interior Galvanized Metal

1 ct OmniPrep Primer
2 cts Interior Finish*

Interior Plaster

1 ct OmniPrep Primer
2 cts Interior Finish*

Interior Poured Concrete

1 ct OmniPrep Primer
2 cts Interior Finish*

Interior Smooth Block

1 ct OmniPrep Primer
2 cts Interior Finish*

Interior Wood

1 ct OmniPrep Primer
(two coats may be necessary)
2 cts Interior Finish*

*For more detailed recommendations, please contact your local Diamond Vogel Sales Representative.

SURFACE PREPARATION

All surfaces must be cured, clean, sound, dry and free of all dirt, dust, efflorescence, wax, oil, grease, chalk and any other contamination that would interfere with new coating adhesion. **Bare surfaces must be properly prepared prior to application of this product.**

Masonry Surfaces-Poured Concrete, Concrete Block:

New concrete and mortar should cure for a *minimum* of 7 days at 72° F (22° C) prior to coating application. Level all surface projections and mortar spatters by stoning. Rake mortar joints clean and remove all soluble salts.

Wood Surfaces: Patch nail holes, cracks and imperfections with spackling compound. Sand and wipe clean. Woods subject to excessive tannin bleeding may require additional coats or an alkyd stain blocking primer.

New Galvanized/Aluminum Metal Surfaces: Solvent wipe to remove surface contamination, then use an etching solution or abrade the surface by sanding.

Weathered Galvanized/Aluminum Surfaces: Hand wash with detergent and rinse thoroughly. The surface must be dull and slightly rough; use an etching solution or sand if needed.

Previously Painted Surfaces

- Hand washing is recommended to remove contamination. If oil or grease is present, use of a cleaner/degreaser is required. All cleaning residue must be completely rinsed from the surface. Allow to dry.
- Remove all loose coatings, deteriorated wood fibers and corrosion by scraping, sanding or other abrading method.
- Patch and fill areas as needed.

Mildew

Remove by using a solution of one (1) part household bleach and three (3) parts water. Apply to mildewed area and scrub. Allow solution to remain on the surface for 3 to 5 minutes then rinse completely and allow to dry before coating application. Do not add ammonia to bleach/water solution.

APPLICATION

- Stir material prior to application. Intermix tinted containers to ensure color uniformity of all material.
- Equipment must be clean prior to start. Flush airless lines with water.
- Apply by brush, roller or spray. A good quality synthetic brush will make application easier. Select a roller cover suited for the texture of the surface to be coated. Airless tip sizes of .015 to .019 are recommended.
- Apply the product in full even coats and maintain a wet edge. For best results when using as a stain blocker, allow 24 hours between coats; two (2) coats may be required for optimum performance.
- Do not thin

ENVIRONMENTAL VARIABLES

Protect product from freezing prior to and during application. Minimum surface and air temperature required for application is 50° F (10° C) and at least 5° F (3° C) above the dew point. Curing is affected by temperature, humidity and air movement. The minimums must be maintained for at least eight (8) hours in order to achieve proper film formation. Application at elevated temperatures, wind conditions, and/or low humidity may require special application procedures to achieve proper film formation.

CLEAN-UP

Clean up spills immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment.

CAUTIONS

Protect from freezing
Do not apply below 50° F
Not intended for use on floors
Do not take internally
Use with adequate ventilation
KEEP OUT OF REACH OF CHILDREN

*WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and wet mop. Before you start, find out how to protect yourself and your family by contacting the national Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

Limited Warranty

The technical data and suggestions for use contained in this document are true and correct to the best of our knowledge at the date of issuance. The statements of this document do not constitute a warranty, expressed or implied, as to the performance of these products. Since Diamond Vogel Paints does not control the application of its products, or the condition of the surfaces to which they are applied, Diamond Vogel Paint's liability will under no circumstances exceed replacement of the product.